

Figure 1

Figure 2a





Figure 2b

## Interface Device

Top View




Figure 3a

Front View



Figure 3b

Back View




Figure 3C

56-700-1  
2000-1-1




Figure 3d




Figure 4

FIG. 5a




Figure 5a




Figure 5b




Figure 5C



# Session File

539

Audio File (e.g. Full guitar track removed, vocals removed, bass removed, etc.)	HTML embedding / JAVA script to record and display information	Path Information to Record and display, speaker, effect settings, etc.	MIDI File to Record Tempo Changes, Program Changes, Key Signature Changes, Position, etc.
540	542	544	546

Figure 5d






Figure 6b

00-0-121  
000

File Edit View Help

600

TONE: Unfiltered

REVERB LUMBER DELAY

MUTE SWITCH

DRIVE BASS MIDDLE TREBLE PRESENCE VOLUME BOOST

MODEL: '90 Marshall 100 W-800 MODEL: '87 '78 Marshall W Stove 70W

DELAY

MASTER VOLUME

NUM REVERB REVERB LENGTH NOISE GATE GATE TIME LINE

GUITARPORT ONLINE ARTIST & GEAR RACKS TONES TUNER HELP 621

12-9 LA Smooth Jazz in C

00:00:00 01:01

Intro Vers... Vers... Endg... Chor... Solo 1 Vers... Vers... Endg... Chor... Outro

Line 6 Original 12-6 LA Smooth Jazz in C 671 Variations: Full Mix KEY

TRACK DETAILS CREDITS LEAD SHEET

Intro 603 605

Level 3 Bb Major	Ab Melodic minor	Bb Major	Ab Melodic minor
Level 2 C Dorian	C Natural minor	C Dorian	C Natural minor
Level 1 C Minor pentatonic			

Cm7 F7 G7#9 Cm7 F7 G7#9

Download Status: click to get detailed information in the Transfer Manager.

Downloads: file

Figure 6C

700




Figure 7a




Figure 7b




Figure 8a

0080 750 111  
0510110

00000




Figure 8b






Figure 8c

852




Figure 8d

674




Figure 8c

0088'0014  
00000000

882




Figure 8f

888




Figure 85

801




Figure 8h

815




Figure 81

900




Figure 9






Figure 10a

Server delivers asset.

1012

Get asset, asset key and indication of owned or rented status from asset database.

~ 1014

Get user key for security device from user database.

~ 1016

Encrypt asset key and rental flag using user key.

~ 1018

Send encrypted key and flag to computing device.

~ 1020

Send encrypted asset to computing device.

~ 1022

Done

~ 1024

Figure 10b




Figure 10c




Figure 10d




Figure 10c




Figure 11




Figure 12a




Figure 12b







Figure 13a



1336

Figure 13b





Figure 14a



1420

Figure 14b




Figure 14c




Figure 15




Figure 16




Figure 17






Figure 18




Figure 19